Unfold for: 2007 Seat and Airbag Wiring Diagram

2007 Seat and Airbag Electrical Schematic



DRAWING NOTES

1. Junctions only occur at intersections with junctions symbol. All other intersections are wire crossings with out junctions!
2. Wires are cut and heat shrunk together.
3. Soldered into cruise control ignition (PINK wire) or cigarette lighter.
4. Hardwire to B-pillar bolt for manual passenger seat only!
5. Connector is 4-pin for manual seat & 6-pin for power seat. Pin location does not change!

KEY

BK	BLACK WIRE	LT	LIGHT ?? WIRE
BL	BLUE WIRE	PU	PURPLE WIRE
BR	BROWN WIRE	RD	RED WIRE
GN	GREEN WIRE	TN	TAN WIRE
GY	GRAY WIRE	WH	WHITE WIRE
GY DOT	GRAY DOT WIRE	YL	YELLOW WIRE
DK	DARK ?? WIRE	??G	WIRE GAUGE