

**Subject:** Kneel system manual release feature.

**Effective:** April 2009.

Replacement actuators for the kneel system are no longer equipped with a cable activated mechanical brake. The manual release cable has been disconnected from the actuator during replacement procedures (disabling the manual release feature). The manual release handle has been removed from the interior of the vehicle. All power features will function normally.

In the event the kneel system is not functioning properly, have the kneel system repaired immediately. **Do not** drive with the rear of the vehicle in the lowered position. Attempting to do so will result in an extremely rough and unstable ride.

Contact your sales representative or call The Braun Corporation at 1-800-THE LIFT. One of our national Product Support representatives will direct you to an authorized service center.

Keep this supplement in the Kneel System section of the operator's manual. The supplement will be available as a reminder that the kneel system manual release feature has been disabled.



*Because Life is a Moving Experience*

631 West 11th Street, Winamac, IN 46996, USA

**1-800-THE LIFT®** [www.braunability.com](http://www.braunability.com)<sup>TM</sup>